

Bungee Cord Replacement

Setup - Tools

Phillips Screwdriver



Step 1



Unscrew the three screws as indicated by red arrow.

Step 2



Fit the replacement bungee into bungee mount. Reinstall the three screws.