

## UNFOLDING AND FOLDING THE CADDYTREK

1. Lay CaddyTrek on flat surface



2. Loosen both knobs as shown below



3. Raise pull bar (at the upper black knobs) up towards you



4. As you lift the pull bar up, the front caster wheels will move forward and unit will unfold.



5. Push frame lock down to secure unit



6. Loosen the upper black knobs to put pull handle into desired position.



7. Retighten all knobs (both black and red)



8. Extend 5<sup>th</sup> wheel (best for going up hills).



**FOLDING THE UNIT: REVERSE THE STEPS**